

Cornhole Game Set

GREAT FOR ON-THE-GO!

BACKYARD
GAMES
SERIES



CORNHOLE SET	
SKU	H2103113BO
Solid Wood Cornhole Board	x 2 (3ft x 2ft)
Stick&Slide Bean Bags	x 8 (6in)
Cornhole Bean Bag Tote Carry Case	x 1 (11.8in x 13.7in)

We'd rather explain the high price of excellent craftsmanship one time than to have to justify poor quality many times over.

- UV Digital Printing
- Water Proof
- Water resistant
- Scratch Resistance
- Prevent Rocking
- Water proof clear coating
- New Zealand Pine Wood
- FSC Environmental Compliance

HOMOTH cornhole boards are made New Zealand pine + A-grade plywood. The surface is UV digital printing. The legs are treated with a transparent waterproof coating, which is ideally suitable for playing indoors and outdoors, no matter what kind of weather and environment it is.

Cornhole Game Set

GREAT FOR ON-THE-GO!

BACKYARD
GAMES
SERIES

HOMOTH



We have tested the water resistance and pattern adhesion of the cornhole board



The standard of the humidity tester is 8-14 degrees.

After half an hour of simulated rain, the humidity of the plate is still within a reasonable range. You don't have to panic about thunderstorms any more. You can take them to the beach or use them at the edge of a swimming pool.



Homothcornhole



homoth_cornhole

Cornhole Game Set

GREAT FOR ON-THE-GO!

BACKYARD
GAMES
SERIES

HOMOTH

Adhesion Test on surface coating ASTM D3359-97:

The purpose of the test is to ensure the cornhole surface coating has adequate adhesion.

Note: 3M Scotch Brand High Performance Filament #893 has been used for the test.



Method:

Cut 9 straight lines about 0.75 in. (20 mm) long and 0.06 in. (1.5 mm) apart through the coating.

Then, cut 9 additional straight lines with the about 0.75 in. (20 mm) and 0.06 in. (1.5 mm) apart, and perpendicular to the first group of lines. Brush the testing area lightly with a soft brush to remove any detached flakes or ribbons. Use 3M 893 tape to the area for 90 seconds. remove the tape.

Remove the tape, you can see it is clean and no paint peeling. Through the magnifier, the edge of the cornhole board is completely smooth, and there is no peeling off the edge of the grid.



The surface of the Cornhole has a special paint treatment to ensure the board surface is not too smooth or too rough. Those treatment can help to provide a good condition for water resistant and the graphic on the board is durable.



Homothcornhole



homoth_cornhole

Cornhole
Game Set
GREAT FOR ON-THE-GO!

BACKYARD
GAMES
SERIES



FAST
TURBO FABRIC



SLOW
MICROSUEDE



homoth cornhole bags are made of a premium microsuede Suede on one side which allows the bag to stick to the surface for extra grip while the opposite side of the bag is made of a carefully selected turbo fabric for easy sliding.

- SLIDES FAST
TURBO FABRIC
- SLIDES SLOW
MICROSUEDE FABRIC
- DOUBLE STITCHED
REINFORCED SEAMS
- FULL COLOR
- ALL-WEATHER PROOF BAG
- REGULATION SIZE AND WEIGHT
15-16OZ

CORNHOLE BAGS	
Cornhole Bags	x 4
Size	6IN
Weight	15-16OZ
Fabric Style	Dual-sided
Stitch Technique	Double reinforced stitching
Fill Type	Resin pellets

Each set includes 4 cornhole bags

Waterproof cover is ideal for various outdoor activities, backyard BBQs, campsites, tailgates and more.




Homothcornhole



homoth_cornhole

CORNHOLE COURT LAYOUT



CORNHOLE RULES

- Boards are placed 27ft from front edge to front edge
- Games are played to 21 points. The first team to reach 21 or over is the winner.
- Woody: Refers to any cornhole bag that has been pitched and remains on the cornhole board playing surface at the conclusion of the frame. Each woody is 1 point. The bag must be on the board and must not have touched the ground before or while on the board to count as a woody.
- Cornhole: Refers to any cornhole bag that has been pitched and passes through the cornhole board hole at any time within the frame. Each cornhole is 3 points.
- Non-scoring bag: Refers to a bag that does not score points. Including: bags on the ground or touching the ground. Bags that are thrown not complying to the rules. Bags that have touched another object (including trees, lines, people, etc) before reaching the board.
- Cancellation Scoring: The approved method of scoring for the sport of cornhole is "cancellation" scoring. In cancellation scoring, the points of one player cancel out the points of their appointment. Using this method, only one team can score in each frame.
- A team member from each team stands at the designated board for the entire game. Game board 1 has a player from team A and team B. Game board 2 has a player from team A and team B.
- Each player stays in their designated lane for the entire game (either to the left or right of the board)
- Top of the frame. Players start the game at board 1 and alternate pitching bags until each player has pitched all 4 of his/her bags. Each player has 20 seconds to pitch each bag. Then the score is taken.
- The opposing player, while not pitching must stand at least 2 feet to the side or rear of the contestant pitching as to not interfere.



Cornhole Game Set

GREAT FOR ON-THE-GO!

BACKYARD
GAMES
SERIES

HOMOTH

- Bottom of the frame. Players at game board 2 alternate pitching bags until each player has pitched all of 4 of his/her bags. Each player has 20 seconds to pitch each bag. Then the score is taken.
- Players must deliver the bag with an underhand release.
- Players feet must stay behind the line of the front of the board at the time of releasing (pitching) the bag.
- Any Cornhole bag that leaves a player's hand once the final forward swing of the delivery process has started shall count as a pitched bag. A bag that is accidentally dropped by a contestant before the final forward swing has started shall not be considered foul and may be picked up and pitched
- All scoring must take place before any of the bags are removed from the board.
- The team that scored in the preceding frame pitches first in the next frame. If neither team scored, then the team who pitched first in the preceding frame shall retain first pitch in the next frame.
- If bags become piled inside the cornhole board and interfere or obstruct with the next pitch or if there is a question whether a cornhole bag would have naturally fallen through the hole, a player may request to have the bags inside the hole removed out of the way.
- Protests – If a contestant desires to make a protest, the protest shall be made to the judge or tournament official at the time the problem occurs. The tournament judge shall make the final ruling on all protests.



Now that you know how to set up and play a game of cornhole, keep practicing! Once you get the hang of throwing the bags, this is a game of strategy. Pick the suited cornhole board and bags for you, and then play with friends/families with this fun game!

Please visit our store or contact us with any questions.

Email: info@homothcornhole.com



Homothcornhole



homoth_cornhole